

Ford Econoline Brake Master Adapter Bracket Instructions

(see http://www.themodernform.com/econoline/econoline_master.html for details with photos)

Wilwood Master Cylinder (260-7563) or other remote reservoir M/C with 2.25" vertical hole spacing is required.

